

彩色印刷
80G哑粉
正反面印刷

Scan this or search 'DOSS fans' on Facebook to join our group, share your experience and find more surprise!

DOSS Technology Co., Ltd
Email: Support@dossav.com

V. Pairing the wireless speaker with your smart device

1. Place your smart device and wireless speaker no more than ten meter away from each other.
2. Press the power button of the speaker for several seconds to turn it on.
3. Set your smart device to "discover" the wireless speaker. Upon powering on, a tone will be heard, the blue LED will start flashing, accompanied by a prompt notifying that the speaker has entered into the pairing mode.
4. Enabled Bluetooth on your device and choose **DOSS MagicBox** from the list.
5. If pairing is successful, the LED will change to steady blue for 5 seconds and your phone will confirm that the connection has been established. If the pairing process fails after 60 seconds, please repeat steps 1 through 5 described above.

VI. Answering and ending a call using your speaker or mobile phone

1. When there is an incoming call, the speaker will generate a tone and a verbal notification to alert you of this event.
2. Briefly press the Handset **▶▶** button to pick up, long press to reject. You may also press the answer button on your smart phone to take the call using the speaker.
3. To end a call, tap the Handset **▶▶** button once again. Likewise, you may also end the call directly using the command on your cell phone.
4. When listening to music using your smart phone, playback will resume automatically once the call has ended.

VII. Product specifications

Battery type: Li-ion 3.7V, 1500mAh
Input: 5V \equiv 1A
Output power: 3W x 1
Unit weight: 0.5 lb
Unit dimension: 3.4 x 1.7 x 3.4 inch
Battery charge up time: 3 hours approximately (when fully depleted).
Battery playback time: up 8 hours
Maximum operation range: 10 meters / 33 ft
Warranty: One-year limited

VIII. Warning

Do NOT drop, hit or shake the device.
Do NOT disassemble, repair or modify the Bluetooth speaker by yourself.
Do NOT use cleaning products that contain benzene, solvents or alcohol.
Do NOT expose the Bluetooth speaker to excessive heat or to direct sunlight for long periods of time.
Do NOT store the device in a place with high humidity or dust.
Do NOT place heavy objects on top of the Bluetooth speaker.
Do NOT use near a microwave oven or wireless LAN products.